

Do not tighten bolts fully until you have completed assembly. DO NOT USE A POWER DRILL TO TIGHTEN THE SCREWS. TIGHTEN BY HAND WITH THE ALLEN KEY PROVIDED.

