

ASSEMBLY INSTRUCTIONS




Office Boffins

A-1 PC




B-1 PC




C-5 PCS



D-1 PC



E-2 PCS



F-6 PCS



30mm

G-4 PCS



20mm

H-4 PCS



Φ16mm

I-4 PCS




Φ23mm


J-1 PC




1 PC



REACM001-K




**Do not tighten bolts fully until you have completed assembly.
DO NOT USE A POWER DRILL TO TIGHTEN THE SCREWS.
TIGHTEN BY HAND WITH THE ALLEN KEY PROVIDED.**




WARNING


- DO NOT STAND ON THIS CHAIR.
- DO NOT USE THIS CHAIR AS A STEP LADDER.
- USE THIS PRODUCT FOR SEATING ONE PERSON AT A TIME ONLY.
- DO NOT USE THIS CHAIR UNLESS ALL BOLTS, SCREWS AND KNOBS ARE FIRMLY SECURED.
- AT LEAST EVERY 6 MONTHS, CHECK ALL BOLTS, SCREWS AND KNOBS TO BE SURE THEY ARE TIGHT.
- IF PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USING THIS PRODUCT UNTIL REPAIRS ARE MADE USING FACTORY AUTHORISED PARTS.
- FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.



Height Adjustable Armrest, Sliding Armpad With Angle Adjustment




Seat Height Adjustment




Seat Depth Adjustment



Independent Back Tilt Adjustment



Independent Seat Angle Adjustment



Back Height Adjustment